


SITE: Seven Out  
BREAK: 2.8  
OTHER: V. 6




FOOT PRINT OF BITE PLAN		STAGE	
CT 6	2'	CD-2	2'
CT 7	2'	CD-3	2'
CT 8	2'	SS-2	EMPTY
DP 1	3'		
DP 2	3'		
CD 1	2'		



SITE: Sewer Out  
 BREAK: 2.8  
 OTHER: v.6

# SEVEN-OUT LLC

## ESTMATED CURRENT VOLUMES OF SLUDGE IN GALLONS



DP1	2,000	RW1	0
DP2	2,000	RW2	6,000
DP3	10,000	ST1	3,000
DP4	2,000	ST2	2,500
SH1	20,000	CT1	1,000
SH2	20,000	CT2	250
SH3	20,000	CT3	250
SH4	20,000	CT4	250
SS1	4,000	CT5	


FOOT PRINT OF SITE PLAN: 1"=20'

CT6	250	CD-2	2,500
CT7	250	CD-3	2,500
CT8	250	SS-2	0
DP1	5,000		
DP2	5,000		
CD1	2,500		

# SEVEN-OUT LLC

## TANK CAPACITIES MAXIMUM LEVEL IN GALLONS

SITE: Seven Out  
 BREAK: 2.8  
 OTHER: V. 6



OP1	<u>20,000</u>	RW1	<u>16,000</u>
OP2	<u>20,000</u>	RW2	<u>16,000</u>
OP3	<u>20,000</u>	ST1	<u>8,000</u>
OP4	<u>20,000</u>	ST2	<u>8,000</u>
SH1	<u>20,000</u>	CT1	<u>8,000</u>
SH2	<u>20,000</u>	CT2	<u>8,000</u>
SH3	<u>20,000</u>	CT3	<u>8,000</u>
SH4	<u>20,000</u>	CT4	<u>8,000</u>
SS1	<u>16,000</u>	CT5	<u>8,000</u>


FOOT PRINT OF SITE PLAN: 1"=20'

CT6	<u>8,000</u>	CD-2	<u>30,000</u>
CT7	<u>8,000</u>	CD-3	<u>30,000</u>
CT8	<u>8,000</u>	SS-2	<u>16,000</u>
DP1	<u>44,000</u>		
DP2	<u>44,000</u>		
CD1	<u>30,000</u>		

SITE: Seven Out  
 BREAK: 2.8  
 OTHER: V.6

BE SURE COVERS  
 ARE IN PLACE

CONTAINMENT  
 SUMP TO  
 BE PUMPED



OP1	_____	RW1	_____	FOOT PRINT OF SITE PLAN - 1"=20'
OP2	_____	RW2	_____	
OP3	_____	ST 1	_____	
OP4	_____	ST 2	_____	
SH 1	_____	CT 1	_____	
SH 2	_____	CT 2	_____	
SH 3	_____	CT 3	_____	
SH 4	_____	CT 4	_____	
SS 1	_____	CT 5	_____	
		CT 6	_____	
		CT 7	_____	
		CT 8	_____	
		DP 1	_____	
		DP 2	_____	
		CD 1	_____	

AREAS OF CONCERN  
 TO PUMP DOWN  
 ENOUGH TO STOP  
 OVERFLOWING

BAKER

BAKER

BAKER

BAKER